


TOP AND CABINET PARTS

AUTOMATIC WASHER

For Model: RAS6233KQ0 (Designer White)




TOP AND CABINET PARTS

For Model: RAS6233KQ0 (Designer White)

IIIus No.	. Part No.	DESCRIPTION
		L'Annahana Danta
1		Literature Parts Installation
		Instructions
	LIT3956025	
	LIT3950025	French
	L113931370	Use & Care Guide
	LIT3955872	English
	LIT3954822	French
	LIT3954540	
	LIT3954578	Wiring Diagram
2 3	8274315	
3	62750	Spacer, Cabinet To
	0==010	Top (4)
4	357213	Nut, Push-In (2)
5	63424	
6	62780	Clip, Top & Cabinet
8	3356311	& Rear Panel (2) Screw & Washer,
0	3330311	Lid Switch (2)
11	3949237	Switch, Lid
13	3351355	Screw, Lid Hinge
.0	0001000	Mounting (4)
15	54584	Hinge, Lid (L.H.)
16	91770	Hinge, Lid (R.H.)
17	19119	Bumper, Lid Hinge
18	21258	Bearing, Lid
		Hinge (2)
19	3361412	Lid
20	358684	
22	9724509	. , , ,
28	3390631	Screw,
0.4	00040	10–16 x 3/8 (5)
31	90016	Clip, Harness

CONTROLS AND REAR PANEL PARTS




FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CONTROLS AND REAR PANEL PARTS For Model: RAS6233KQ0

(Designer White)

Illus.	Part		Illus.	Part		Illus.	Part	
No.	No.	DESCRIPTION	No.	No.	DESCRIPTION	No.	No.	DESCRIPTION
			-					
1	3976300	Washer, Water	10	8055003	Clip, Harness	27	3366912	Clamp, Hose
		Inlet Hose (4)			& Pressure Hose	28		Screw, 10-24 x 3/8
		(1-1/16 x 5/8)	11	661612	Switch, Rotary	29		Screw, 8-18 x 3/8
2 3	8274378	Knob, Control			(Temperature)	30	3363366	Clamp, Hose
3		Hose, Water	12		Switch, Water Level	31		Clamp, Hose
		Inlet (2)	13		Bracket, Control	32	3951449	Hose, Pump To Tub
		Blue Coupler	14		Cord, Power			(Includes #30)
	3949375	Red Coupler	15	3952821	Strain Relief,	33	8318201	Clip, Capacitor
4	3357027	Nozzle-Drain			Power Cord	34	661606	Capacitor,
		Hose	16		Cap, End (L.H.)			Motor Start
5		Strap, Console (2)	17	3400073	Screw, Ground	36	3400818	Screw, Timer
6		Panel, Rear			(Console)			Mounting
7		Pad, Rear Panel	18	3952164	Valve, Water	39	3954258	Panel, Console
8	3951609	Hose, Drain			Mixing	44		Knob, Timer
		(4 ft.)	19	90864	Screw,	45	8274395	Dial, Timer
	661577	Hose, Drain			10-24 x 1/2	49	388326	Screw, 8-18 x 1.25
		(9 ft.)	20		Screw, 10-16 x 3/8			(Panel to Top)
		(Not Included)	21	370451	• •	50	9740848	Screw
	3357090	Extension,	22	3357328	Hose, Vacuum	51		Cap, End (R.H.)
		Drain Hose			Break	55	3390647	Screw
		(21 Inches.)	23		Clamp, Hose	56	3366913	Clamp, Drain
		(Not Included.)	24	387606	Break, Vacuum			Hose
9	3953146	- ,	25	8519200	Support, Rear	60	3348424	Shield, Suds
		(60 Hz.)			Panel	61	3955021	Harness, Wiring
		(Motor Not A	26	3361805	3			(For Detail See
		Service Part)			Assembly	l		Pages 9 & 10)

AGITATOR, BASKET AND TUB PARTS For Model: RAS6233KQ0



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST 5

AGITATOR, BASKET AND TUB PARTS For Model: RAS6233KQ0


(Designer White)

Illus. No.	Part No.	DESCRIPTION
1	3355758	Cap, Agitator
2		Screw & Washer
5	63235	Agitator
6	63851	Tub Ring
7	3359585	Gasket, Tub Ring
8	21366	Nut, Spanner
9	3951989	Basket And
		Balance Ring
10	3952746	Filter, Plate
11	63849	Tub
13	389140	Block, Drive
14	383727	Gasket, Centerpost
15	3347780	Hose, Pressure
		Switch
16	3949550	Washer

BRAKE, CLUTCH, GEARCASE, MOTOR AND PUMP PARTS For Model: RAS6233KQ0


		. Or model. 1	Designer White)			
@	Illus.	Part	boolgilor Times,	Illus.	Part	
	No.	No.	DESCRIPTION	No.	No.	DESCRIPTION
	1	388952	Brake & Drive Tube (Complete) (Refer to Page 11 For Further	10 11		Screw, Gearcase To Base (3) Plate, Motor Mount To
1——	2	63292	Breakdown) Washer, Spin Tube Thrust	12 13		Gearcase Grommet, Motor (4) Coupling, Motor
2	3	62697	Ring, Spin			And Isolation
3	4	63283	Tube Support Ring, Retainer	14 15	3946532 3355454	Shield, Motor Clip,
4	5 6	3951311 3951308	Clutch (Complete) Band & Lining,	16	3400516	Anti–Rattle
			Clutch (Includes	17	3349637	Retainer, Motor (2)
5	7	62646	Illus. 7 & 8) Cap, Clutch	18	3362089	Shield, Tub To Motor
	8	3946792	Spring (2) Spring, Clutch	19	661599	Motor, Main Drive
	9	3360630	Gearcase (Complete)	20	62850	Switch, Main
8			(Refer To Page 12 For Further	21 22	3363394	Drive Motor Retainer, Pump (2) Pump (Complete)
			Breakdown)	23	3387485	Screw, 10–16 x 5/8
9 10 11/12 13 13 14	16		17 23		20	

MACHINE BASE PARTS



WIRING HARNESS PARTS For Model: RAS6233KQ0

or Model: RAS6233KQU (Designer White)



WH2G

WIRING HARNESS PARTS For Model: RAS6233KQ0


For Model: RAS6233KQ0 (Designer White)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1 2 3 4	388498 3347812 3352501	Clip, Harness Clip, Harness Clip, Harness Clip, Harness	13		Block, Disconnect (Motor 3 Speed) (Use Term. 94613 Or 94614.)	23 24 25	60687	Connector, Etc Connector, Relay (Use Term.308569) E.T.C. Control
5 6 7	3390496	Clip, Harness Clip, Harness Retainer, (Suds Models)	14 15 16		Block, Disconnect (Use Term. 352088) Protector Connector	26	3948617	Connector (T.P.A.) (3–Circuit) (Lid Switch) (Use Term. 3948619
8	352090		17		(2–Way) (Use Term.94614) Plug, Terminal	27	3360056	OR 3948620.)
9		Timer, Block Disconnect (Black)			(4–Way) (Power Cord) (Use M3 Screws)			(Pressure Switch) (Use Term.3948619 OR 3948620.)
10	62889	Receptacle, Terminal (3–Way) (Lid Switch) (Use Term.94613)	18 19		Clip, Harness Block, Disconnect (12–Way) (Timer) (Use Term. 94613)	28	3354925 3354926	Block, Connector (Cold Valve) (Use Term.693217) Block, Connector (Hot Valve)
11	353424	Or 94614.) Plug, Terminal (3–Way) (Power Cord) (Use Term.94613)	20	3347730 388818	Receptacle (6–Way) (Use Term. 94613) Plug, Terminal (12–Way)	30	3948615	(Use Term.693217) Connector (T.P.A.) (6–Circuit) (Temp. Switch) (Use Term.3948619
12	62505	Block, Disconnect (Motor 2 Speed) (Use Term.352088)	22	3369366	(Use Term. 94613 Or 94614.) Timer, Block Disconnect (Black) (Amp) (Use Term.3369365)			OR 3948620.)

FOR COMPLETE WIRING HARNESS REFER TO CONTROL AND REAR PANEL PARTS PAGE

BRAKE AND DRIVE TUBE PARTS

For Model: RAS6233KQ0



Illus. No.	Part No.	DESCRIPTION
1	388952	Brake And Drive Tube (Complete)
2 3 4	62658 91939 356427	Ring, Thrust Seal, Oil Seal, Drive Tube
5 6	356937 64027	Spacer, Drive Tube Tube Reaket
0	64027	Tube, Basket Drive (Includes Illus. 3, 4, 5 & 9)
7	64035	Ring, Retaining
8	64232	Shoe, Brake
9	62703	"T" Bearing, Spin Tube
10	62648	Cap, Brake Spring (2)
11	387806	Spring, Brake
12	62909	Sleeve, Brake Spring
13	63023	Cam, Brake Release
14	63022	Sleeve, Cam
15	64194	Driver, Brake Cam
16	90368	Ring, Retaining


FOLLOWING PARTS NOT ILLUSTRATED

285208 Lubricant (Use Only In Brake Shoe Assembly On Roller & Pin)

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST


GEARCASE PARTS


For Model: RAS6233KQ0



WATER SYSTEM PARTS

For Model: RAS6233KQ0 (Designer White)






WS400

Illus. No.	Part No.	DESCRIPTION
1	285442	Connector Kit, Plastic Drain Hose
2	285321	Sleeve Kit, (Contains 2 Sleeves)
3	370447	Clamp, Hose
4	16272	Connector, Straight
5	285320	Siphon Break Kit (Not Included)
6 7	65349 367031	Clamp, Hose Drain Protector (Not Included)

MISCELLANEOUS PARTS

For Model: RAS6233KQ0 (Designer White)



Illus. No.	Part No.	DESCRIPTION
1	3976263	Miscellaneous
2	3976300	Parts Bag Washer, Inlet Hose
3		(1-1/16 x 5/8) (4) Clamp, Hose
4 5		Nut, Lock (2) (3/8–16) Foot, Front (2)
6		Clamp, Hose

OPTIONAL PARTS (NOT INCLUDED)

Illus. Part No. No. DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
PAINT, TOUCH-UP (1/2oz.)	OIL			SEAL	.ER	
72017 White		350572	Oil, Gearcase (16 Oz.)		285195	Sealer, Gasket (.20 Fl. Oz.) (6 ml)
PAINT, PRESSURIZED SPRAY (12 oz.) 350938 Primer, Gray 350930 White PAINT, BULK (1 qt.) 799344 White (Uncut)	LUBF	285208	Lubricant (Use Only in Brake Shoe Assembly On Roller and Pin)	;	367031	, , , ,